NoiseKen

QUICK START GUIDE

Space-Magnetic Field Visualization System

EPS-02Hv2

NOISE LABORATORY CO., LTD.

Edition 2.00

AEA00097-00E-1

Contents

1. INTRODUCTION 1
2. INCLUDED ITEMS 1
3. SYSTEM REQUIREMENTS 2
4. SETUP MEDIA CONTENTS 2
5. SETUP PROCEDURE 2
6. SUPPORT NETWORK 3

NOTICE

- The content of this guide is subject to change without prior notice.
- The reproduction or transfer of this guide in any form whatsoever is prohibited without the prior written permission of the Noise Laboratory Co., Ltd. (NoiseKen).
- Please contact NoiseKen if you find any unclear points, errors, omissions, or other inconsistencies.
- NoiseKen will not be liable for any damages that occur due to improper usage of this product by the customer, failure to follow the information in this product manual, or repair or modifications performed by a third party other than NoiseKen or a party designated by NoiseKen.
- The trademarks and company names appearing in this guide are trademarks or registered trademarks of their respective companies. In this guide, the trademark symbol (TM) and registered symbol (R) are omitted.

1. INTRODUCTION

Thank you for purchasing the EPS-02Hv2 Space-Magnetic Field Visualization System. The setup procedure is described below.

Also, please read this guide together with the instruction manual in the setup media.

2. INCLUDED ITEMS

Before starting use, check that the parts and accessories below are included with the product.

A

B

C

D

E

F

G

H



I

A: Web camera	
・ Main Part	1
・ Warranty	1
B: USB extension cable (2 m)	1
C: Setup media (EPS-02Hv2)	1
D: USB protect key	1
E: Camera tripod	
・ Main Part	1
・ Storage bag	1
F: Extension pole	1
G: Japanese Quick Start Guide	1
H: English Quick Start Guide (This guide)	1
I: Storage case	1

* The key of A, C, G and H are included in the upgrade version, and the key of C is disk media.

* The key of C, D, G and H are included in the secondary license version, and the key of C is disk media.

3. SYSTEM REQUIREMENTS

Check the following system requirements before setup.

OS	Microsoft Windows 10 (Japanese / English version) Microsoft Windows 11 (Japanese / English version)
CPU	Dual Core 2.4 GHz or faster recommended
Memory	8 GB or more recommended
Storage	5 GB or more
Display	1366 × 768 dots or more 1920 × 1080 dots recommended
Other	・ Operation cannot be guaranteed when using online storage or software that uses cloud services. ・ 3 empty USB ports

* The upgrade version and the secondary license version require a DVD drive for installation. The magnetic field measuring instrument driver require a DVD drive for installation.

* If software with high CPU utilization is running, the operation may become unstable.

* Refer to the manufacturer's website for the latest operation warranty of each device such as camera.

4. SETUP MEDIA CONTENTS

The contents of the setup media are as follows.

EPS-02Hv2
JSP USB
MANUAL

(1) EPS-02Hv2 folder
The EPS-02Hv2 installers are stored.

(2) JSP USB folder
The USB protect key drivers are stored.

(3) MANUAL folder
The PDF files of the instruction manual for EPS-02Hv2 are stored.

5. SETUP PROCEDURE

Log on to Windows with an ID that has administrator privileges and follow the steps below to setup.

＜In the case of upgrade version＞

Follow steps (1) and (4) to upgrade. It is not necessary to uninstall the EPS-02H software beforehand. When the EPS-02H software is not needed, uninstall it using "Uninstall or change a program" in "Control Panel".

(1) Installation of the USB protect key driver

① Insert the USB protect key into the USB port of the PC.

② Select "unknown devices" or "HardKey" of "other devices" in Device Manager and install the driver. The driver file is located in the [JSP USB] folder of the setup media.

(2) Installation of Magnetic Field Measuring Instrument Driver

① Connect the magnetic field measuring instrument and PC using a USB cable, and turn on the power to the magnetic field measuring instrument.

② Insert the CD attached to the magnetic field measuring instrument into the DVD drive, and execute [driverSetup.msi] in the [English] folder.

③ The installation program will start. Follow the instructions on the screen to install.

(3) Installation of the EPS-02Hv2 software

① Load the setup media and execute [EPS-02Hv2_En.msi] in the [EPS-02Hv2]-[English] folder.

② The installation program will start. Follow the instructions on the screen to install.

* If a previous version of EPS-02Hv2 software is already installed, uninstall it before performing the installation.

6. SUPPORT NETWORK

If a symptom which seems a trouble is found, check the symptom, software version, model name of connected device, and serial number, and inform this information to Noise Laboratory or your nearest sales agent of Noise Laboratory.

NOISE LABORATORY CO., LTD.
1-4-4, Chiyoda, Chuo-ku, Sagamihara City, Kanagawa Pref.,
252-0237, Japan
TEL: +81-(0)42-712-2051 FAX: +81-(0)42-712-2050
URL: http://www.noiseken.co.jp
Printed in Japan